

**COIN COLLECTORS — PREPAY**  
**174C, D, G, H**  
**COMMON BATTERY — CONNECTIONS**

**Note 1:** In some upper housings, transfer contacts may be designated Y, BB, YY, W, and BK-YY, respectively.

**Note 2:** Dotted lines in diagram show manual set connections.

**Note 3:** When a 61R filter is required for radio-frequency suppression, move yellow dial lead from Y upper housing contact spring to filter bracket terminal and connect filter leads as follows:

Yellow lead to filter bracket terminal

Black lead to No. 5 upper housing contact

Red lead to Y upper housing contact.

