

COIN COLLECTORS — PREPAY
176 (C, D, G, H)
COMMON BATTERY — CONNECTIONS

Note 1: In some upper housings, transfer contacts may be designated W, BB, YY, BK-YY, and Y, respectively. Terminal 5 is always furnished.

Note 2: Dotted lines in diagram show manual set connections.

Note 3: When a 61R filter is required for radio frequency suppression, move yellow dial lead from Y upper housing contact spring to filter bracket terminal and connect filter leads as follows:

Yellow lead to filter bracket terminal

Black lead to No. 5 upper housing contact

Red lead to Y upper housing contact.

